

INSTRUCTIONS FOR FILLING

TECALEMIT GREASE GUN G.C. 3020.

UNSCREW CAP AND REMOVE PISTON ASSEMBLY FILL GUN BARREL TO WITHIN $1\frac{1}{4}$ " OF TOP, AVOIDING AIR BUBBLES IN THE GREASE.

PUSH PISTON ASSEMBLY DOWN THROUGH GREASE UNTIL HIGH PRESSURE PISTON IS FELT TO ENGAGE ITS CYLINDER, PUSH CORK FOLLOWER PISTON FIRMLY DOWN ON TO SURFACE OF GREASE SO THAT ROOM IS LEFT FOR THE CAP TO BE REPLACED.